Interface Converter Overview Version 0.9 – July 2009

Name:	Photo:	Description:	Application (KELLER-Devices):	Product No.			
RS 232 0 TTL							
K-101		Converter cable with 2-pole connector: Interface converter RS232 to TTL-Level	Intelligent Manometers und Calibrators	309010.0001			
		RS232 🛛 RS485					
K-102		 Converter with plug clamp: converts RS232 to RS485 half-duplex RS 232-connection: 9-pole D-Sub-plug RS 485-connection: 3-pole screwable plug clamp (RS485 A, RS485 B, GND) automatic switching between send/receive supply through RS232-Interface baud rates: 9,6kbit / 115kbit 	Series 33-39, LEO 1, LEO 2, LEO 3, dV2-PS	309010.0004			
K-102I		Converter (isolated) with plug clamp: like K-102, but: • supply connection for transmitter (V+, GND): • galvanic isolation of communication line supply unit (15V/200mA) is necessary and included in delivery □ see Product No.	Series 33-39, LEO 1, LEO 2, LEO 3, dV2-PS	Europe: 309010.0012 UK: 309010.0023 USA: 309010.0024			
K-107 (substitutes K-106)		Converter set like K-102, but includes: transmitter supply with integrated 9 Volt Battery or supply unit Binder- and D-Sub 9-pole (RS232) connection CD with Read30/ Prog30 software supply unit for European, UK or American sockets see Product No.	Series 33-39, LEO 1, LEO 2, LEO 3, dV-22 PP dV-2 PS	Europe: 309010.0003 UK: 309010.0020 USA: 309010.0021			
	RS232 I RS485 (for autonomous data collectors)						
K-103		Converter cable with Binder socket: Like K-102, but with cable (length: 2m) and Binder socket instead of plug clamp.	DC-22 G (∅ 46mm)				
K-103A		Converter cable with Fischer plug: Like K-102, but with cable (length: 2m) and Fischer plug instead of plug clamp.	DCX-22, DCX-22 AA, DCX-22 VG, DCX-22 SG, LEO Record, LEX 1	309010.0002			



Name:	Photo:	Description:	Application (KELLER-Devices):	Product No.				
		USB → RS485						
K-104		 Converter with plug clamp: Supply through USB for 1 transmitter (U_{out} = 10V /I_{max} = 20mA) DC-socket for external supply (12 – 20 Volt DC), if more connected transmitters needed galvanic isolation from supply and communication screwable plug clamp with connection for RS485 (A, B) and supply (+V, GND) LED for indication of communication activity cable (length: 1,8m) for connection to USB-Interface included in delivery driver software also included in delivery. On the internet: http://www.ftdichip.com/Drivers/VCP.htm 	Series 33-39, LEO 1, LEO 2, LEO 3, dV2-PS	309010.0008				
K-104B	0 0	Converter cable with Binder socket: like K-104, but instead of plug clamp with cable (2,1m) and Binder socket with RS485A/B and supply: 1: GND 2: 3: +Vcc 4: RS485A 5: RS485B Transmitter supply for direct connection to a series 33-39 transmitter (like K-107) The driver software is included in delivery. On the internet: http://www.ftdichip.com/Drivers/VCP.htm	Series 33-39, LEO 3, dV-22 PP dV-2 PS	309010.0010				
	USB → RS485 (for autonomous data collectors)							
K-104A	0	 Converter cable with Fischer plug: Fischer plug for connection of RS485A/B (without supply) cable length: 1,8m galvanic isolation of communication LED for indication of communication activity driver software also included in delivery. On the internet: http://www.ftdichip.com/Drivers/VCP.htm 	DCX-22, DCX-22 AA, DCX-22 VG, DCX-22 SG, LEO Record, LEX 1	309010.0009				

	Converter Accessories						
Name:	Photo:	Description:	Accessories for:	Product No.			
Cable option 1		Cable adapter Binder plug to cord clamp (for connection to series 33-39)	K-104B, K-107	309010.0014			
Cable option 2	Face	Cable adapter Binder plug to 5-pole Leoco-Socket (for connection to Leo 3 and elderly versions of series 33-39 -> before year 2002) With tool for removing socket.	K-104B, K-107	309010.0015			
Cable option 3		Cable adapter Binder plug to 6-pole Molex socket (for connection to actual series 33-39 transmitter)	K-104B, K-107	309010.0016			
Cable option 4		Cable adapter cord to 2-pole socket (for connection to LEO 1 and LEO 2)	K-102, K-102l, K-104	309010.0017			
Cable option 5	1	Cable adapter 5-pol Binder to 8-pol Binder (for connection to dV-2 PS, dV-2 PP and Castello) Pin assignment 8-pole: 1: - 5: RS 485 A 2: - 6: - 3: - 7: RS 485 B 4: +Vcc 8: GND	K-104B, K-107	309010.0041			
Handheld Adapter		Handheld Adapter: Required to connect a handheld (Palm, Pocket PC) with a interface converter. 9-pol D-Sub male male 1 2 3 4 5 6 7 8 9 9 9 9 9 9 1 2 3 4 5 6 7 8 9 9 9 9 9 9 1 2 3 4 5 6 7 8 9 9 9 9 9 9 1 1 2 3 4 5 6 7 8 9 9 9 9 9 9 1 1 2 3 4 5 6 7 8 9 9 9 9 9 9 9 9	K-103A, K-107	309010.0028			
Supply unit Europe	4Cb	Supply unit 15V - Europe • for connection to DC-Socket • Input: 230VAC • Output: 15VDC, 210mA	K-102I, K-104, K-104B, K-107	309010.0025			
Supply unit UK		Supply unit 15V - UK for connection to DC-Socket Input: 230VAC Output: 15VDC, 150mA 	K-102I, K-104, K-104B, K-107	309010.0026			
Supply unit USA	E	Supply unit 15V – USA • for connection to DC-Socket • Input: 120VAC • Output: 15VDC, 210mA	K-102I, K-104, K-104B, K-107	309010.0027			