

GSM-2 description of communication

1	Email-structure	2
2	Command.....	2
3	Command table.....	3
3.1	#B Base64.....	3
3.2	#C Additional information about e-mail content.....	3
3.3	#E End	3
3.4	#F Message type	3
3.5	#G Text	3
3.6	#I Info	4
3.7	#M Measurement	4
3.8	#O Ack (16Bit value)	4
3.9	#T Time	4
3.10	#X CRC16	5
4	Configuration	5
4.1	#a GPRS settings (char max 50).....	5
4.2	#b TEXT E-Mail-adr. & SMS-Tel.N° & Inst.Dat. (char 10-50)	5
4.3	#k TEXT FTP Settings (char 10-50)	6
4.4	#c measurement settings (byte/integer)	7
4.5	#f measurement settings 2 (byte/integer)	8
4.6	#d floating-point values (single).....	9
4.7	#e correct time / miscellaneous / commands	10
5	RECORD.....	11
5.1	Memory-Map	11
5.2	Header	12
5.3	Data packet	12
6	Examples configuration	13
7	SMS Messages from GSM-2	14
7.1	General	14
7.2	Messages/Functions	14
7.3	Data format of a SMS.....	14
7.3.1	Description of Message format.....	14
7.3.2	Sample for Measure-Function/Message	15
7.3.3	Example for Info-Function/Message.....	17
7.3.4	Example for Alarm-Function/Message	18
7.3.5	Example for Check-Function/Message	19
8	E-Mail Messages (Example).....	21
8.1	Configuration sent from GSM	21
8.2	Message from GSM-2 / Record-Format	21
8.3	Message from GSM-2 / Text-Format.....	22
9	FTP Messages (Example)	23
9.1	Configuration sent from GSM	23
9.2	Record data interpretation (Base64)	23
9.3	Example decoding Base64 from measurement file	24
10	Hardware Information's	26
10.1	General information about configuration GSM-2	26
10.2	GSM-2 device type overview.....	26
10.3	28
10.4	Evolution of GSM-2 firmware.....	29

1 Email-structure

Header	1. Received: from..	sending time determination, to compare with system time GSM-2 module
Subject	Tel-Nr [M,S] Example: +41793076790 M +00111223344 S	mobile phone number 13 characters (International without blank) from GSM-2-module M : to Datamanager (=measurement) S : to GSM-2-module (=settings) Broadcast (Message for all participants, not yet supported)
Body		List of commands that are consecutively ranked

2 Command

general structure of a command:

[Command] **/** [variable name1] **=** [+,-] [variable value 1] / [variable name 2] = [+,-] [variable value 2]

#	Command start character
[command]	command consists one sign, (could be more signs in future)
/	delimiters of different data containers
[variable name]	variable that is communicated
=	delimiters
[+,-]	sign of the variable value (not required for strings)
[variable value]	value of variable

Regular Expression for Validation using Mail or FTP:

```
((#B+/[a-zA-Z0-9]+=?[^+]=A-Za-z0-9@]*)(#[A-Za-z]+(/[a-zA-Z0-9]+=?[_\s]!?\s:|,-\+).A-Za-z0-9@\%\<>(\^\^)*))(*(#E/e)?(#X/a=\d{5})?';
```

limited character set:

Because of the command structure of GSM-2, *certain characters are forbidden to use* when parameterize the GSM-2 (for example with GSM2 Setup).

Please remind that GSM-2 only support the ASCII Character Set, from ASCII value 33 126.

The following ASCII values are prohibited: "space" , #, /, =, "
(-> ASCII value 32, 34, 35, 47, 61)

not supported characters for SMS only:

[] { } ~ ^ \ " €

3 Command table

3.1 #B Base64

#B		Firmware Version		
#B	/a	08.28	#B/a=[Base64 encoded content]	The content (base-64 code) contains the control characters / =

3.2 #C Additional information about e-mail content

#C		Firmware Version		
	/a	08.28	Range 0 ... 4095	Record-Data Page-start
	/b	08.28	Range 0 ... 30	Record-Data Page-numbers

3.3 #E End

#E		Firmware Version		
	/e	/e		end of e-mail or ftp-file

3.4 #F Message type

#F		Firmware Version		
	/a	12.20	Example: /a=0	measurement-E-Mail/FTP-File
	/b	09.49	value 0 = periodic Mail value 1 = unsolicited Mail	Configuration -E-Mail without ACK (sending by config button or periodically sent) From version 09.45 only periodically INFO-E-Mail
	/c	12.20		Alarm-E-Mail /FTP-File
	/d	12.20		Configuration-E-Mail /FTP-File with ACK (response to configuration changements) From version 09.45 config button Ack = 0
	/e	12.20		Record-Data /FTP-File
	/f	12.20		requested Record-Data / FTP-File

3.5 #G Text

#G			
	/a		Text to measuring values
	/b		Text to alarm
	/c		Text to answer

3.6 #I Info

#I		Firmware Version		
	/n	08.28	N=12345678 [max 8 CHR]	Serial number GSM-2-module
	/s	08.28	/s=24 [0...31]	Signal quality GSM-Network
	/b	08.28	/b=99 [0...100]	calculated Battery capacity [%]
	/f	08.28	/f=08.04 [YY.KW]	Software version GSM-Module
	/v	09.49	V=3.912 [x.xxx]	measured battery voltage GSM-2-module [V]

3.7 #M Measurement

#M		Firmware Version		
	/a	09.49	+0.12-14.25+25.15	current values (only selected channels)
	/b	09.49	+0.12-14.25+25.15	recorded values (only selected channels)
	/c	08.28	+0+1	State of digital-Inputs (0 or 1)
	/d	09.49	+0.0004080+0.9559831+0.0000000 +0.0000000+24.482742+0.0000000 +0.9555750+25.100002	current values (All available channels)

3.8 #O Ack (16Bit value)

#O		Firmware Version		
	/f	08.28	/f=23423	PC to GSM Request Ack from receiver (GSM-2)
	/g	08.28	/g=23423	GSM to PC return Ack (answer GSM to PC)
	/h	08.28	/h=23423	return NotAck (GSM do not accept ack)

3.9 #T Time

#T		Firmware Version		
	/s	08.28	GSM-Time	s for seconds, beginning 1.1.2000 0:0:0 [0...2^32]
	/p	08.28	GSM-Provider time If network operator does not support System Clock Update Message, the initial date, time and time zone, displayed could be invalid when function is not supported, GSM-2 returns date ~1.1.2000	Example: 08.02.06,16:12:21+04 ASCII string of format: yy.MM.dd,hh:mm:ss±zz or yy.MM.dd,hh:mm:ss yy - 2-digit year [2000-2069] MM - 2-digit month [01-12] dd - 2-digit day of month [00-31] hh - 2-digit hour [00-23] mm - 2-digit minute [00-59] ss - 2-digit seconds [00-59] zz - (optional) time zone offset from GMT, in quarter-hours [-47...+48]. If this value is not specified, the time zone offset will be 0.
	/m	08.28	same format as second (s) from year 2000	Time, last measured value was stored

	/d	08.28	/d=354221.21234 (for manual Parser)	Time as float Integer : days since 30.12.1899 decimal places: Time
--	----	-------	-------------------------------------	--

3.10#X CRC16

#X		Firmware Version		
	/a	08.28	Example: /a=05473	CRC as decimal number 0- 2^16 always 5-digits Can be appended at the end of message (in unencrypted state = readable)

4 Configuration

4.1 #a GPRS settings (char max 50)

#a		Firmware Version		
	/a	08.28	24	GprsAPN
	/b	08.28	48	GprsID
	/c	08.28	40	GprsPassword
	/d	08.28	15	GprsDNS
	/e	08.28	24	Smtp showed Name
	/f	08.28	48	PopUsername
	/g	08.28	40	PopPassword
	/h	08.28	48	OptSmtpUsername
	/i	08.28	40	OptSmtpPassword
	/j	08.28	40	Pop3Server
	/k	08.28	5	Pop3Port
	/l	08.28	40	SmtpServer
	/m	08.28	50	SmtpPort
	/n	09.49	50	ReturnAddress
	/o		50	OptReturnAddress (not existing)

4.2 #b TEXT E-Mail-adr. & SMS-Tel.N° & Inst.Dat. (char 10-50)

#b		Firmware Version		
	/a	08.28	50	EmailAddress1
	/b	08.28	50	EmailAddress2
	/c	08.28	50	EmailAddress3
	/d			Reserve(Address4)
	/e			Reserve(Address5)
	/f			
	/g	08.28	10	password for query SMS
	/h		previously serial number, but never used	
	/i			
	/j	08.28	10	SimPin
	/k	08.28	30	recall for data connection (not used for GSM-2)

/l			
/m	08.28	30	SmsNumber1 Measure
/n	08.28	30	SmsNumber2 Alarm
/o	08.28	30	SmsNumber3 Info
/p			Reserve(SmsNumber4)
/q	09.09		SMS-Service center nr.
/r	08.28	20	NetworkName
/s	08.28	30	OwnTelNumber
/t	08.28	20	LocationName
/u	09.01	50 (new 160)	SmsText1 Measure
/v	09.01	50 (new 160)	SmsText2 Alarm
/w	09.01	50 (new 160)	SmsText3 Answer Check
/x			Reserve(SmsText4)
/y			Reserve(SmsText5)
/z			
/0	09.01	20	LongitudeText
/1	09.01	20	LatitudeText
/2	09.01	20	AltitudeText

4.3 #k TEXT FTP Settings (char 10-50)

#k		Firmware Version		
/a	12.20	50		FTP Server Name
/b	12.20	50		FTP Username
/c	12.20	50		FTP Password
/d	12.20	50 (not used in GSM, but supervised)		FTP Account
/e	12.20	(Max 5 letters range 0...65535)		FTP source control (Port)
/f	12.20	(Max 5 letters range 0...65535)		FTP destination control (Port)
/g	12.20	(Max 5 letters range 0...65535) (is fixed 2000 into GSM)		FTP source data (Port)
/h	12.20	50		FTP Server Path
/i				
/j				
/k				
/l				
/m				
/n				
/o				
/p				
/q				
/r				
/s				
/t				
/u				
/v				
/w				
/x				
/y				
/z				
/0				

	/1		
	/2		

4.4 #c measurement settings (byte/integer)

#c		Firmware Version		
F100/1	/a	08.28	_U32(start measurement date = now (GSM clock) + 60 days. If start measurement date < now (GSM clock) then start measurement date = now (GSM clock))	Timer 0 Measure
F100/2	/b	08.28	_U32(start alarm date = now (GSM clock) + 60 days. If start alarm date < now (GSM clock) then start alarm date = now (GSM clock))	Timer 1 Alarm
F100/3	/c	08.28	_U32(start info date = now (GSM clock) + 60 days. If start info date < now (GSM clock) then start info date = now (GSM clock))	Timer 2 Info
F100/4	/d	08.28	_U32(start check date = now (GSM clock) + 60 days. If start check date < now (GSM clock) then start check date = now (GSM clock))	Timer 3 Check
F100/5	/e	08.28	_U32(start data connection date = now (GSM clock) + 60 days. If start data connection date < now (GSM clock) then start data connection date = now (GSM clock))	Timer 4 Data connection
	/f			
F100/6	/g	08.28	_U32 (smallest measurement interval: 1 second, biggest interval: 30days)	Interval 0 Measure
F100/7	/h	08.28	_U32 maximal now (GSM clock) + 30 days	Interval 1 Alarm
F100/8	/i	08.28	_U32 maximal now (GSM clock) + 30 days	Interval 2 Info
F100/9	/j	08.28	_U32 maximal now (GSM clock) + 30 days	Interval 3 Check
F100/10	/k	08.28	_U32 maximal now (GSM clock) + 30 days	Interval 4 Data connection
	/l			
F100/11-0	/m	08.28	(1 Byte) If channel0 is active, Bit0 = 1	measure / save CH 0...7 CH0= Bit0, CH1=Bit1....
F100/11-1	/n	08.28	(1 Byte)	(SaveMethode)
F100/11-2	/o	08.28	(1 Byte)	SendSmsAfterXMeas
F100/11-3	/p	09.01	(1 Byte) If channel0 is active, Bit0 = 1	measure / save CH 8...15 CH8= Bit1, CH9=Bit2....
F100/11-4	/q	08.28	(1 Byte)	SendMailAfterXMeas
F100/12-0	/r	08.28	(1 Byte)	AlarmCH-Nr.
F100/12-1	/s	08.28	(1 Byte)	Alarm Type 1 = On / Off 2 = Delta 3 = Digital Input
F100/12-2	/t	08.28	(1 Byte)	SendAlarmXTimes
	/u			
F100/14-0	/v	08.28	(1 Byte) Min is 2, Max is 9	Resolution pressure channels
F100/15-0	/w	08.28	(1 Byte) Min is 2, Max is 9	Resolution temperature channels
F100/16-0	/x	08.28	(1 Byte) only bit 3 is set / read	LockTimer only Check BitPos 3 Check

F100/16-0	/y	08.28	(1 Byte) Bit 3 can not be set	Lock_Timers (without Check) BitPos 0 Measure BitPos 1 Alarm BitPos 2 Info BitPos 3 Check BitPos 4 Dial
F100/16-1	/z	08.28	(1 Byte) At least minimal e-mail is set for GSM Configuration: To ensure that a Check Function is always active, when CheckFTP switched off CheckMail is automatically activated	SendSmsEmail BitPos 0 Measure-SMS BitPos 1 Alarm-SMS BitPos 2 Info-SMS BitPos 3 Check-SMS BitPos 4 Measure-Mail BitPos 5 Alarm- Mail BitPos 6 Info- Mail BitPos 7 Check- Mail
F100/16-2	/0	08.28	(1 Byte)	Modem Protocol (V32, V34, V110)
	/1	09.01	(1 Byte)	AccountSetting 0 = off Bit0 = send Ssl Bit1=receive Ssl
F100/16-4	/2	08.28	(1 Byte) 0 = same login 1 = different login for SMTP	ServerConfig
F100/28-3	/3	09.01	(1 Byte)	ofl.Form-Type
F100/18-2	/4	08.28	(1 Byte)	Power External Device
F100/18-3	/5	08.28	(1 Byte) (not writable!)	Supported Connection Types
F100/18-4	/6	08.28	(1 Byte)	Connection Type
F100/28-2	/7	09.01	(1 Byte) (get ignored from Datamanager version 2.3 or higher)	KonfigBytes0 0 = wlc.Sensortype = vg 1 = wlc.Sensortype = sg
F100/28-0	/8	09.01	(1 Byte)	calc.Channels 0 = P1-P2 1 = P1-Baro 2 = P1 relative 255 = not defined (YSI)
F100/28-1	/9	09.01	(1 Byte)	calc.conversionTo 0 = Height of Water 1 = Depth to Water 2 = Height of Water above Sea 3 = Overflow (Poleni) 4 = Overflow (Thomson)

4.5 #f measurement settings 2 (byte/integer)

#f		Firmware Version		
F100/31	/a	09.09	U32(start eventdetectmeasure date = now (GSM clock) + 60 days. If start eventdetectmeasure date < now (GSM clock) then start eventdetectmeasure date = now (GSM clock))	Timer 5 EventDetectMeasure
	/b	08.28		
	/c	08.28		
	/d	08.28		
	/e	08.28		
	/f	08.28		
F100/32	/g	09.09	U32 maximal now (GSM clock) + 30 days	Interval 5 DetectEvent
F100/33	/h	09.09	U32 maximal now (GSM clock) + 30 days	Interval 6 MeasureEvent
	/i	08.28		
	/j	08.28		
	/k	08.28		
	/l	08.28		

F100/30-0	/m	09.09	(1 Byte)	EventCH
F100/30-1	/n	09.09	(1 Byte) change only when < 4	EventType 0 = deactivated 1 = activated (data transmitted as record) 2 = On / Off 3 = Delta
F100/30-2	/o	09.09	(1 Byte) Max 30	SendMailYTimes
	/p			
F100/26-1	/q	12.20		SendFTPAfterXMeas
	/r			
	/s			
	/t			
	/u			
	/v			
	/w			
	/x			
	/y			
F100/26-4	/z	12.20	(1 Byte) for GSM Configuration: To ensure that a Check Function is always active, when CheckFTP switched off CheckMail is automatically activated	SendFTP BitPos 0 Measure-FTP BitPos 1 Alarm-FTP BitPos 2 Info-FTP BitPos 3 Check-FTP
	/0			
	/1			
	/2			
F100/18-1	/3	12.41		ExtPowPreSetTime 0...254 255 = 0
	/4			
	/5			
	/6			
	/7			
	/8			
	/9			

4.6 #d floating-point values (single)

#d		Firmware Version		
F30/0	/a	08.28		Alarm On
F30/1	/b	08.28		Alarm Off
F30/2	/c	08.28		Alarm Delta
	/d			
	/e			
F30/3	/f	08.28	must not be 0 otherwise changed to 1, only positive value possible	Multiplier temperature channels
F30/4	/g	08.28	must not be 0 otherwise changed to 1, only positive value possible	Multiplier pressure channels
	/h			
F30/6	/i	09.09	Event_Val_1	Val 1 (On Val) Event-Logging
F30/7	/j	09.09	Event_Val_2	Val 2 (Off Val) Event-Logging
F30/8	/k	09.09	Event_Val_3	Val 3 (delta) Event-Logging
	/l			

F30/10	/m	09.01	Floats for water-configuration etc.	Val 100 1 = WLC enabled
F30/11	/n	08.28		Val 101 wlc.length
F30/12	/o	08.28		Val 102 wlc.height
F30/13	/p	08.28		Val 103 calc.offset
F30/14	/q	08.28		Val 104 wlc.density
F30/15	/r	08.28		Val 105 ofl.width
F30/16	/s	08.28		Val 106 ofl.angle
F30/17	/t	08.28		Val 107 ofl.form-Factor
F30/18	/u	08.28		Val 108 ofl.minCalc
F30/19	/v	08.28		Val 109 (Fu30/31 Index 19)
F30/20	/w	08.28		Val 110 (Fu30/31 Index 20)
	/x			(Fu30/31 Index 21)
	/y			(Fu30/31 Index 22)
	/z			(Fu30/31 Index 23)
F30/24	/0	08.28		Longitude (Fu30/31 Index 24)
F30/25	/1	08.28		Latitude (Fu30/31 Index 25)
F30/26	/2	08.28		Altitude (Fu30/31 Index 26)
	/3			
	/4			
	/5			
	/6			
	/7			
	/8			
	/9			

4.7 #e correct time / miscellaneous / commands

#e		Firmware Version	
	/a	09.01	_U32 (Time in seconds, from 1.1.2000) Data-request start - time
	/b	09.01	_U32 (Time in seconds, from 1.1.2000) Data-request end - time
	/t	08.28	t=+30 maximal +/- 172800 seconds = +/- 2 days Time

water level configuration with float

(Firmware >= 09.01: replaced by 3 bytes #c/7/8/9)

1. Installation / Calculation:

transfer array of 4 Bytes as Float :

Byte 0 : sensor type
 0 : relative VG
 1 : absolute SG

Byte 1 : calculation rule:
 0 : Level over level probe(e)
 1 : depth to water surface (f)
 2 : height of water to sea level(g)

Byte 2 : Installation: (On GSM always B)
 0 : Installation depth (B)
 1 : depth to water surface(C)

Byte 3: 0

encryption

Cipher = Plain*2 – key[x mod 64]
Plain = (Cipher + key[x mod 64])/2

key : phone-nr: [+41793945311]
x : running variable that takes one character after the other

5 RECORD

5.1 Memory-Map

The total memory is divided in pages. The number of pages may vary depending on the device type. GSM-2 currently contain 4096 pages (2MBit memory). Each page consists of 64 bytes. The first 8 byte are used as header. All following bytes are actual data. A data set consists of four byte. These include the measured variable / channel and the corresponding measured value.

total memory: 4096 pages (2MBit)

Page	description
0	start data memory
1	
2	
...	
...	
X-1	end data memory
X	start record-text
...	
...	
4095	end record-text

1 page with 64 byte :

Byte	description
0	Header
1	
2	
3	
4	
5	
6	
7	
8	Data 1
9	
10	
11	
12	Data 2
13	
14	
15	
...	...
...	...
...	...
60	Data 14
61	
62	
63	

5.2 Header

The header consists out of 8 byte.



Byte	header description	remark
0	start detection / overflow counter / start pointer	"unimportant on GSM-2"
1	remaining 8 bits of the start pointer	start pointer
2	absolute Time 1. Byte1	absolute time in seconds since 01.01.2000
3	absolute Time 2. Byte2	($2^{24} \cdot \text{Byte1} + 2^{16} \cdot \text{Byte2} + 2^8 \cdot \text{Byte3} + \text{Byte4}$)
4	absolute Time 3. Byte3	
5	absolute Time 4. Byte4	
6	reserved	
7	reserved	

Byte 0:

- Bit 7 **Start detection** – if this bit is set, this means that this page is the beginning of a record.
- Bit 5 + 6 **Overflow counter** – is incremented when the last page has been reached and it begins again at the first page.
- Bit 0 .. 4 Together with the whole second byte of the header, this represents the **start pointer**. He displays the page, where the record was started.
5 Bit + 8 Bit = 13 Bit

5.3 Data packet

Data 1 ... 14

A data packet consists of 4 bytes. There are four types of data packets:

a) Data packet with variable / channel / time delay to last measurement / value

Byte	description	
0	Bit 7..4: variable/channel ,0000' to ,1110' (0..14)	Bit 3..0: time interval to the previous data packet(0..15s)
1		measuring value 3. Byte
2		measuring value 2. Byte
3		measuring value 1. Byte

The measuring value is a 4 byte float, where the last byte is omitted

b) Data packet time delay

Byte	description	
0	Bit 7..4: ,1111'	Bit 3..0: ,0000'
1		time delay to the previous data packet 3. Byte
2		time delay to the previous data packet 2. Byte
3		time delay to the previous data packet 1. Byte

A data packet with time delay get saved, when time delay to previous data packet is higher than 15 seconds.

$$\text{time delay} = 2^{16} * \text{Byte1} + 2^8 * \text{Byte2} + \text{Byte3} = \text{range } (0..16'777'215 \text{ s})$$

c) data packet with text content*„unimportant on GSM-2“*

Byte	description	
0	Bit 7..4: ,1111'	Bit 3..0: ,0100'
1		8-Bit-ASCII- characters
2		8-Bit-ASCII- characters
3		8-Bit-ASCII- characters

It is possible to store a text packet with 3 characters (3byte)

→ this function is not used into GSM-2. This function is a preparation for may future customer requests and cannot be used by the user at this moment.

d) empty data packet*„unimportant on GSM-2“*

Byte	description	
0	Bit 7 .. 4: ,1111'	Bit 3 .. 0: ,1111'
1		,xxxx xxxx'
2		,xxxx xxxx'
3		,xxxx xxxx'

An empty data packet indicates an empty data packet or the end of a record.

A new record always starts on a new page.

6 Examples configuration

measurement:

```
#F/a=1#T/s=1028646345#M/a=-1.1+2.2+3.3+4.4+5.5+6.6/c=+1+0#E/e#X/a=60770
```

configuration (correct time +43 seconds)

```
#C/t=+43#X/a=48542
```

7 SMS Messages from GSM-2

7.1 General

The messages from and to the GSM-2 are in TEXT – Mode (PDU-Mode is not supported). A message contains maximum 160 letters.

7.2 Messages/Functions

The GSM-2 can send different Short-Messages:

- **Measurement-Message**
The GSM-2 measure in a defined interval all selected channels and transfer them together in 1 message.
- **Info-Message**
All useful information about the GSM-2 are sent in a defined interval in 1 message.
- **Alarm Message**
An alarm message will be sent if an alarm condition is true
- **CHECK message (Answer to a command)**
The GSM-2 will answer to a SMS command if a message is sent to it.

The functions are activated by enabling the corresponding functions in General Settings by the GSM Setup program (Please note the Manual for more information).

7.3 Data format of a SMS

7.3.1 Description of Message format

The GSM-2's short message format can be set according the users need.

Identifier

Mainly the sender is identified by its telephone number. The telephone number is included in the short message.

Time information

The time information, when the short message is sent is included in each short message, that is the time when the last measurement took place. You can use that time information to assign a time to the last values in the text message. The time information of the other values are calculated (the measure interval is known, it is a setting).


Text

At the beginning of the message you can set an individual text for example to identify the message.

Data

The measurements follow direct after the “text” and each value is separated by a + or – sign. All values are in that order how they are listed in the “Measuring channels / Save channels” setting and in that order how they are measured. That means the first value is the oldest, the last value is the newest.


Short message containing measurements




7.3.2 Sample for Measure-Function/Message

This is a sample of a Measure-short message sent from the GSM-2. The GSM-2 is set up like in the picture below.

Settings	Settings for the sample	Description
Measuring channels / Save channels	Pd ; TOB1 ; PBaro ; TBaro	The selected channels will be transferred by SMS
Amount of characters for data transfer (Pd / P1 / P2 / Volt.Inp.)	6	The values will be transferred with this amount of characters
Amount of characters for data transfer (temperature values).	4	The values will be transferred with this amount of characters
Measure interval	1 Minute	All selected are measured in this interval
Amount of measurements (sent in 1 SMS)	5	The SMS message is sent after X measurements
Text at the beginning of the message	measurement	Individual text at the beginning of the message could be used to identify the message type



Short message containing measurements




Message with calculated time information and sorted and separated measuring values


Sender / Identifier	Type of Message	Time	Pd	TOB1	PBaro	TBaro
+41793076790	measurement	03.11.2010 13:42	-0.0053	+23.5	+0.9695	+24.7
		03.11.2010 13:43	-0.0052	+23.5	+0.9695	+24.7
		03.11.2010 13:44	-0.0051	+23.5	+0.9695	+24.8
		03.11.2010 13:45	-0.0051	+23.5	+0.9694	+24.9
		03.11.2010 13:46	-0.0051	+23.6	+0.9694	+24.9

7.3.3 Example for Info-Function/Message

This is a sample of an Info-short message sent from the GSM-2.
The GSM-2 is set up like below in the picture.



Info short message




Message body

SIGNAL:20 BATTERY:99% VALUES:-0.0045+0.9722+0.0000+0.00+25.3+0.00+0.9767+26.1+0.0000+0.0024


Keyword	Value / Meaning
SIGNAL:	The value after the keyword SIGNAL shows the signal quality of the GSM-2 antenna. The value is 0 through 31 covers the range of -113 dbm (or less) to -51dbm (or greater).
BATTERY:	Indicates the calculated per cent of remaining battery capacity. Range 0...99
VALUES:	All available actual values (measured at "Timestamp") are listed. Resolution defined in settings tab.

7.3.4 Example for Alarm-Function/Message

This is a sample of an Alarm-short message sent from the GSM-2.
The GSM-2 is set up like below in the picture.



Alarm short message



Message body

Alarmtext-0.0045+25.2+0.9766+25.6 Inputs:0.0


Individual text at the beginning of the message could be used to identify the message type

All available actual values (measured at "Timestamp") are listed. Resolution defined in settings tab


Keyword	Value / Meaning
Inputs:	Status of the digital inputs (0 = open 1 = closed)

7.3.5 Example for Check-Function/Message

This is a sample of a answer in the Check-short message, sent from the GSM-2. The GSM-2 is set up like below in the picture.



Responses to the command “?”




Message body

Answer-Text-0.0045+25.1+0.9767+26.0

Individual text at the beginning of the message could be used to identify the message type

All enabled actual values (measured at "Timestamp") are listed. Resolution defined in settings tab

Responses to the command “i”




Message body

SIGNAL:19 BATTERY:99% VALUES:-0.0044+0.9722+0.0000+0.00+25.0+0.00+0.9767+25.9+0.0000+0.0097

Keyword	Value / Meaning
SIGNAL:	The value after the keyword SIGNAL shows the signal quality of the GSM-2 antenna. The value is 0 through 31 covers the range of -113 dbm (or less) to -51dbm (or greater).
BATTERY:	Indicates the calculated per cent of remaining battery capacity. Range 0...99
VALUES:	All available actual values (measured at “Timestamp”) are listed. Resolution defined in settings tab.

8 E-Mail Messages (Example)


8.1 Configuration sent from GSM



```


#F/d=0#T/s=311703059/p=09.11.16,17:10:40+04#M/a=+0.0000000+0.0000000+0.0000000+0.0000000+0.9622050+26.100002+0.0000000+0.0000000/c=+0+0/d=+0.0000000+0.0000000+0.0000000+0.0000000+0.0000000+0.9622050+
0.0000000+0.0000000+0.0000000+0.0000000+0.0000000+0.0000000+0.0000000+0.0000000+0.0000000+0.0000000+0.0000000+0.9622050+
0.000#I/n=123/s=19/b=99/f=09.45/v=+3.947#a/a=gprs.swisscom.ch/b=gprs/c=gprs/d=
000.000.000.000/e=Gautschi/f=mail@mail.com/g=XXXXXX/h=gsm2@keller-
druck.ch/i=XXXXXX/j=pop.keller-druck.ch/k=110/l=smtpt.keller-druck.ch/m=25/n=
mail@mail.com #b/a= mail@mail.com /b= mail@mail.com /c= mail@mail.com
/g=keller/j=1234/k=+41796131929/m=+41796131929/n=+41796131929/o=+4179613192
9/q=+41794999000/r=TestSW9.45/s=+41793695330/t=+41793695330/u=Messung/v=Ala
rmtext/w=Antwort-
Text/0=8.72586111111111/1=47.5026833333333/2=450.0000000#c/a=311703060/b=3
07530600/c=307530600/d=311704800/e=307530600/g=180/h=60/i=60/j=1800/k=60/m=
211/n=0/o=1/p=3/q=20/r=1/s=1/t=1/v=6/w=5/x=8/y=9/z=210/0=0/1=0/2=0/3=0/4=4/
5=7/6=5/7=0/8=1/9=0#f/a=311704800/g=240/h=120/m=0/n=2/o=1#d/a=+15.000000/b=
+14.000000/c=+0.000000/f=+1.000000/g=+1.000000/i=+0.100000/j=+0.050000
/k=+0.100000/m=+1.000000/n=+10.00000/o=+455.00000/p=+0.000000/q=+998.20
000/r=+1.000000/s=+0.000000/t=+0.000000/u=+0.000000/v=+987654290/w=+987
654290/0=+8.7258620/1=+47.502680/2=+450.00000#o/g=58979#e/e
```

8.2 Message from GSM-2 / Record-Format



```
#F/e=0#C/a=905/b=1#T/s=311703050/p=09.11.16,17:10:40+04#M/a=+0.0000000+0.0000000+0.0000000+0.9622050+26.100002+0.0000000+0.0000000/c=+0+0#I/n=123/s=19/b=99/f=09.45/v=+3.947
#B/a=Q34S1DP7AABAQcaAYD92WHBBzzOAAAAAkD0gAPAAALQAPgx7ED+Mu0BBxzBgP3ZYcEHQzIAAAACQPHAA/z/7YA==#E/e#X/a=35185
```

8.3 Message from GSM-2 / Text-Format



```
#F/a=0#T/s=295535946/p=09.05.13,15:20:06+08/n=295535916#M/b=
+0.9629475+26.04997+0.0170898+0.2099609+28.540000+0.000000+0.000000+2.4779999+0.000000+0.000000+0.000000+13.941998+0.0509999-2.500000+5.400000
+0.9629450+26.00000+0.0170898+0.2075195+28.520000+0.000000+0.000000+2.4810000+0.000000+0.000000+0.000000+13.941998+0.0509999-2.400000
+5.400000+0.9629450+26.00000+0.0146484+0.2070312+28.490000+0.000000+0.000000+2.4920000+0.000000+0.000000
+13.941998+0.0509999-2.500000+5.400000+0.000000+0.000000+13.941001+0.0499999-2.500000+5.400000+0.000000+0.000000
+2.4850002+0.000000+0.000000+13.941001+0.0499999-2.500000+5.400000+0.000000+0.000000+13.941001+0.0499999-2.500000+5.400000+0.000000+0.000000
+28.440000+0.000000+0.000000+2.4890000+0.000000+0.000000+13.941001+0.0499999-2.500000+5.400000+0.000000+0.000000
+25.900002+0.0146484+0.2026367+28.430000+0.000000+0.000000+2.4900000+0.000000+0.000000+13.941001+
0.0499999-2.500000+5.300000+0.9629324+25.90002+0.0122070+0.201953+28.400001+0.000000+0.000000+2.4740000+
0.000000+0.000000+13.941001+0.0499999-2.500000+5.400000+0.9629250+25.850000+0.0122070+0.1977539+28.359996+
0.000000+0.000000+2.4850002+0.000000+0.000000+13.941001+0.0499999-2.500000+5.400000+0.9629250+25.799999+
0.0122070+0.1977539+28.340000+0.000000+0.000000+2.4740000+0.000000+0.000000+13.941001+0.0509999-2.400000
+5.300000+0.9629475+25.799999+0.0122070+0.1953125+28.300000+0.000000+0.000000+2.4799999+0.000000+0.000000+
13.941001+0.0499999-2.500000+5.400000+0.9629475+25.799999+0.0122070+0.1953125+28.279999+0.000000+0.000000+
2.4799999+0.000000+0.000000+13.941001+0.0499999-2.500000+5.400000+0.9629125+25.749997+0.0097656+0.1928711+
28.239999+0.000000+0.000000+2.4840000+0.000000+0.000000+13.941001+0.0499999-2.500000+5.400000+0.9628500+
0.850000+0.0097656+0.1904296+28.210000+0.000000+0.000000+2.4779999+0.000000+0.000000+13.939998+
0.0499999-2.500000+5.300000+0.9628449+25.799999+0.0097656+0.1904296+28.180000+0.000000+0.000000+2.4720000+
0.000000+0.000000+13.939998+0.0499999-2.500000+5.300000+0.9628923+25.850000+0.0097656+0.1879882+28.149997+
0.000000+0.000000+2.4850002+0.000000+0.000000+13.939998+0.0499999-2.500000+5.400000+0.9629025+25.799999+
0.0097656+0.1879882+28.109999+0.000000+0.000000+2.4779999+0.000000+0.000000+13.939998+0.0499999-2.500000+
5.400000+0.9628799+25.799999+0.0097656+0.1855468+28.079996+0.000000+0.000000+2.4980000+0.000000+0.000000+
13.939998+0.0489999-2.500000+5.300000+0.9628750+25.850000+0.0097656+0.1904296+28.210000+0.000000+0.000000+
2.4850002+0.000000+0.000000+13.938999+0.0489999-2.400000+0.9628300+25.700000+0.0085449+0.1831054+
28.000000+0.000000+0.000000+2.4860000+0.000000+0.000000+13.938999+0.0489999-2.500000+5.400000+0.9628250+
25.700000+0.0073242+0.1831054+27.970000+0.000000+0.000000+2.4790000+0.000000+0.000000+13.937998+
0.0480000-2.400000+5.400000/c=+0#I/n=123/s=26/b=99/f=09.05/v=+4.014#g/a=Messung#E/e#X/a=32502
```

9 FTP Messages (Example)

9.1 Configuration sent from GSM

```
#F/d=0#T/s=443025550/p=14.01.14,15:38:49+04#M/a=+0.0004080+0.9559831+0.0000
000+24.482742+0.9555750+25.100002/c=+1+1/d=+0.0004080+0.9559831+0.0000000+
.0000000+24.482742+0.0000000+0.9555750+25.100002#I/n=1416/s=17/b=99/f=12.40
/v=+3.823#a/a=gprs.swisscom.ch/b=gprrs/c=gprs/d=000.000.000.000/e=GDemo/f=g
sm_xx@gsmdata.ch/g=yourpassword/h=gsm_xx@gsmdata.ch/i=
yourpassword/j=pop.gsmdata.ch/k=110/l=smtmp.gsmdata.ch/m=587/n=gsm_xx@gsmdata
.a.ch#b/a=datamanager_xx@gsmdata.ch/b=demo@keller-druck.ch /c=demo@keller-
druck.ch/g=j/k=/m=+41781234567/n=+41781234567/o=/q=+41794999000/r=KELLERD
EMO/s=+41798101088/t=DemoStation/u=station keller/v=alarm message
body/w=/o=8.747837/1=47.497869/2=450.000#c/a=443027701/b=443025541/c=631144
800/d=442926000/e=631144800/g=3000/h=60/i=86400/j=86400/k=86400/m=215/n=0/o
=3/p=0/q=1/r=4/s=1/t=1/v=4/w=4/x=0/y=3/z=0/0=0/1=0/2=0/3=0/4=4/5=7/6=3/7=0/
8=1/9=0#f/a=431005483/g=3600/h=3600/m=1/n=1/o=1/q=1/z=15#d/a=+10.000000/b=+
9.0000000/c=+0.0010000/f=+1.0000000/g=+1.0000000/i=+0.9000000/j=+1.2000000/
k=+5.0000000/m=+1.0000000/n=+9.1180000/o=+400.00000/p=+0.0000000/q=+1000.00
00/r=+1.0000000/s=+0.0000000/t=+1.0000000/u=+0.0000000/v=+10.000000/w=+11.0
00000/0=+8.7478370/1=+47.497869/2=+450.00000#k/a=ftp.gsmdata.ch/b=datamanag
er_xx@gsmdata.ch/c=yourpassword/d=datamanager_xx/e=21/f=21/g=2000/h=#0/g=43
607#E/e
```

counsel: When working with plain text transmission, recognize first which GSM-2 device type is active (**#c/6=**) and check afterwards the activated channels (**#c/m=** and **#c/p=**) to know the measurement values order. This information only gets transmitted with configuration files, but not with normal measurement files.

Message:	#c/6=3	=	GSM-2 device type 3
	#c/m=215	=	11010111
	Active channels →		CH0, CH1, CH2, CH4, CH6, CH7
	#c/p=0	=	0

#M/a=+0.0004080 (CH0) +0.9559831 (CH1) +0.0000000 (CH2)
+24.482742 (CH4) +0.9555750 (CH6) +25.100002 (CH7)

9.2 Record data interpretation (Base64)

When "record function" is activated on GSM-2, the stored measurement data get compromised to base64 code and transferred by email or ftp file additional to the plain text. As each GSM-2 device type has its own channel assignment, the overview on page 29 shows for each GSM-2 type the related channel assignment.

The GSM-2 device type information is transmitted with the configuration file at the beginning (announcement) of a measuring task.

9.3 Example decoding Base64 from measurement file

original text file

```
#F/e=0#C/a=2347/b=5#T/s=443010632/p=14.01.14,11:31:02+04#M/a=+2.2168779+5.7929690+0.958
2375+25.549998+2.2195887+2.4568239+2.3946847/c=+1+1#/l/n=1935/s=14/b=22/f=12.40/v=+4.189
#B/a=A+YaZ8X4AADQBmN8AABlhBADdRAQK8UYD91V3BBz5mgQA3/sEAdf8BAGYTbAAE2E
EAN1UBAsgRgP3VRcEHQzAPmGmfIUAACoEAN/7BAHXXAQBi68AABlxBADdhAQLMAYD91TX
BBz5mgQA4BsEAzSBagWzwAAE1EEAN2EBAtfID5hpnyqgAAAGA/dU1wQc4AoEAOA7BAHVn
AQB1g8AABlxBADdtAQLbuYD91TXBBzgCgQA4HsEAdUMBAGVb/Qc4AA+YaZ80BAAAQQA3d
QEC5YGA/dVBwQcxmoEAOCrBAHUTAQBiL8AABIRBADeFAQLigYD91T3BBzGagQA4NsEAdP
APmGmfOlgAAwEAZQv9BzgCgQBE2sEAfr8BAG53wAAE2EEATFUBAUqhgP3v2cEHOZqBAEU
SwQB+XwEAhf9AF5U=#E/e#X/a=780
```

Put that string into a BASE64 to Decimal converter, as one on the web page: <https://conv.darkbyte.ru/>

The screenshot shows the "Online converter" interface. The "Text" input field contains the green-highlighted "Original text file" content. The "Convert" button is highlighted in green. The "Decimal" output field displays the converted decimal code in red. The "Message Digest / Checksum" section shows the MD5 hash as f6b2'. The "Tags cloud" section contains various technical terms.

Please note: be aware that no spaces, carriage return or line feed are copied into the window

Converted BASE64 (green) to Decimal (red) code

3 230 26 103 197 248 0 0 192 64 25 141 240 0 1 34 16 64 13 212

interpret data

// Header (consists of 7 Bytes)

3 230 26 103 197 248 0 0

start pointer record : Byte0 = 3 = 00000011, Byte1 = 230 = 11100110, start pointer = 00011111001110

start pointer absolute time [s] from 01.01.2000 = $2^{24} \cdot \text{Byte1} + 2^{16} \cdot \text{Byte2} + 2^8 \cdot \text{Byte3} + \text{Byte4}$
 $= (26 \cdot 16777216) + (103 \cdot 65536) + (197 \cdot 256) + 248 = 443008504 \text{ seconds from 01.01.2000}$
 $\underline{\underline{= 10:56:05 / 14.01.2014}}$

// first data package (consists of 4 Bytes)


192 64 25 141

Byte0 = 192 = 11000000

= selected channel = 1100 = 12

converting Bytes to IEEE754 (Byte0 = 255 (default))

measuring value of channel 12 = 2.399291



// second data package (consists of 4 Bytes)

240 0 1 34

Byte0 = 240 = **11110000**

When Byte0 = 240 = 11110000 then data package information is about data packet time delay

data package time delay (to last data package)= = $2^{16} \cdot \text{Byte3}(0) + 2^8 \cdot \text{Byte2}(1) + \text{Byte3}(34) = \underline{\underline{290}}$ seconds (4min 50s) =

// end of record or empty data package

255 0 ~~15~~ 7

Byte0 = 255 = **11111111** = represents empty package or end of record.

Byte1 + Byte2 + Byte3 getting ignored. A new record starts always on a new page.

10 Hardware Information's

10.1 General information about configuration GSM-2

Variable values are scanned and only ASCII characters in the range > 31...< 123 get processed.
 Remaining characters get ignored! Commands are only processed in range 0...9 as a...z as A...Z.
 Anything else get ignored.

10.2 GSM-2 device type overview

GSM device type	channels
Type (0) RS485	1: Pd (P1-P2) [bar] 2: P1 [bar] 3: P2 [bar] 4: T [°C] 5: TOB1 [°C] 6: TOB2 [°C]
Type (1) RS485 & 2 Dig.Inp	1: Pd (P1-P2) [bar] 2: P1 [bar] 3: P2 [bar] 4: T [°C] 5: TOB1 [°C] 6: TOB2 [°C]
Type (2) RS485 & Baro (P1-P2) & Dig.Inp.1	1: Pd (P1-PBaro) [bar] 2: P1 [bar] 3: P2 [bar] 4: T [°C] 5: TOB1 [°C] 6: TOB2 [°C] 7: PBaro [bar] 8: TBaro [°C]
Type (3) RS485 & Baro (P1-PB) & Dig.Inp.1	1: Pd (P1-P2) [bar] 2: P1 [bar] 3: P2 [bar] 4: T [°C] 5: TOB1 [°C] 6: TOB2 [°C] 7: PBaro [bar] 8: TBaro [°C] 9: Volt. Inp. 1 [V] 10: Volt Inp. 2 [V]
Type (4) RS485 & Baro (P1-P2) & Dig.Inp.1 & Volt Inp.	1: Pd (P1-PBaro) [bar] 2: P1 [bar] 3: P2 [bar] 4: T [°C] 5: TOB1 [°C] 6: TOB2 [°C] 7: PBaro [bar] 8: TBaro [°C] 9: Volt. Inp. 1 [V] 10: Volt Inp. 2 [V]

Type (5) RS485 & Baro (P1-PB) & Dig.Inp.1 & Volt Inp.	1: Pd (P1-P2) (1) [bar] 2: P1 (1) [bar] 3: P2 (1) [bar] 4: T (1) [°C] 5: TOB1 (1) [°C] 6: TOB2 (1) [°C] 7: PBaro [bar] 8: TBaro [°C] 9: Volt. Inp. 1 [V] 10: Volt Inp. 2 [V]
Type (6) RS485(x5) & Baro (P1-P2) & Dig.Inp1/2 = Counter Inp. & Volt Inp. * The <u>state</u> of both digital inputs (0 or 1) is transmitted as plain text (#M/a=/c=+1+1) in addition to the counter input number which is transmitted in plain text and additional, as record in base64	1: Pd (P1-P2) (1) [bar] 2: P1 (1) [bar] 3: P2 (1) [bar] 4: T (1) [°C] 5: TOB1 (1) [°C] 6: TOB2 (1) [°C] 7: PBaro [bar] 8: TBaro [°C] 9: Volt. Inp. 1 [V] 10: Volt Inp. 2 [V] 11: P1 (2) [bar] 12: P1 (3) [bar] 13: P1 (4) [bar] 14: P1 (5) [bar] 15: Counter input * [dimensionless]
Type (7) SDI12 & Baro & Digital Inp.1 & Volt Inp	1: not used 2: PBaro [bar] 3: TBaro [°C] 4: Volt Inp.1 [V] 5: Volt Inp.2 [V] 6: SDI12 CH1 7: SDI12 CH2 8: SDI12 CH3 9: SDI12 CH4 10: SDI12 CH5 11: SDI12 CH6 12: SDI12 CH7 13: SDI12 CH8 14: SDI12 CH9 15: SDI12 CH10
Type (8) RS485 (5xP1+TOB1) & Baro & Dig.Inp. 1/2 * The <u>state</u> of both digital inputs (0 or 1) is transmitted as plain text (#M/a=/c=+1+1) in addition to the counter input number which is transmitted in plain text and additional, as record in base64	1: P1 (1) [bar] 2: TOB1 (1) [°C] 3: P1 (2) [bar] 4: TOB1 (2) [°C] 5: P1 (3) [bar] 6: TOB1 (3) [°C] 7: P1 (4) [bar] 8: TOB1 (4) [°C] 9: P1 (5) [bar] 10: TOB1 (5) [°C] 11: Volt Inp.1 [V] 12: Volt Inp.2 [V] 13: PBaro [bar] 14: TBaro [°C] 15: Counter input * [dimensionless]

Type (9) RS485 CTD & Baro (P1-P2) & Dig.Inp. 1 & Volt. Inp.	1: Pd (P1-P2) [bar] 2: P1 [bar] 3: P2 [bar] 4: T (Conductivity) [°C] 5: TOB1 [°C] 6: TOB2 [°C] 7: P Baro [bar] 8: T Baro [°C] 9: Volt Inp.1 [V] 10: Volt Inp.2 [V] 11: Conductivity Tc [mS/cm ²] 12: Conductivity raw [mS/cm ²]
Type (10) RS485 CTD & Baro (P1-PB) & Dig.Inp. 1 & Volt. Inp.	1: Pd (P1-PBaro) [bar] 2: P1 [bar] 3: P2 [bar] 4: T (Conductivity) [°C] 5: TOB1 [°C] 6: TOB2 [°C] 7: P Baro [bar] 8: T Baro [°C] 9: Volt Inp.1 [V] 10: Volt Inp.2 [V] 11: Conductivity Tc [mS/cm ²] 12: Conductivity raw [mS/cm ²]

10.3

10.4 Evolution of GSM-2 firmware

Firmware Number	implemented functions / comments	published
08.28	First release	22.07.2008
09.48	adaption for battery D	27.11.2009
09.49	adaption for battery DD	27.11.2009
12.20	FTP communication	31.05.2012
12.29	Function barometric sensor offset correction (PBaro)	17.01.2012
12.32	extension to use 4MBit memory	11.02.2013
12.40	transmit measurement data if channel value change (delta) immediately	17.06.2013
15.50	Adaption for DCX-22AA CTD	01.12.2015